

Harmony Fountain

Instructions

- **Read all instructions before operating the fountain.**
 - **Place the fountain on a waterproof surface only. Occasional splashing or condensation is to be expected.**
1. Unpack the fountain and thoroughly rinse or wipe all parts to remove any dust or debris.
 2. Locate the tube inside the fountain and slide the end of the tube over the pump nozzle. Secure the tube to the pump nozzle with the zip tie provided. After securing the tube, use scissors to trim off the excess zip tie.
 3. Place the pump inside the fountain so that it rests on the floor. You will need to allow a loop of the electrical cord to rest on the bottom of the fountain to enable the pump to be properly located.
 4. Fill the fountain with water until it completely covers the pump. Only the pump and a portion of the electrical cord should come into direct contact with the water.
 5. Do not plug in the cord or use this product if any part of the pump or power cord appears to be damaged in any way.
 6. Do not operate the fountain unless the pump is completely submerged in the water. Operating the pump when not fully submerged will cause damage.
 7. If you plan to add rocks to the fountain, place them in the water before plugging in the fountain.
 8. Use the toggle switch on the cord to turn the pump on and off. When first turned on, it may take a few minutes for the air to be pumped out of the hose and the water to start flowing. This is a normal part of the pump operation.
 9. Operate this unit only under adult supervision. Do not allow it to operate while unattended.

Maintenance

1. If you have high mineral content in your tap water, use distilled water to prevent mineral build-up on the fountain and pump.
2. If debris gets caught in the intake vents in the pump, disconnect the cord from any power source and rinse the pump under running water.