


UNIFORM WARES

M40



User instructions

Setting the time

1. Adjust the watch crown (A), situated on the side of the case at the 3 o'clock mark, out from the Operating Position to Set Position 2 (P2), where the crown is fully extended at the second adjustment click. You will notice the second hand stops ticking.
2. Turn the crown clockwise to the desired time. DO NOT turn the crown anti-clockwise.
3. When the time is set, push the crown back to the Operating Position and the second hand will resume.

Setting the date

1. Adjust the watch crown out from the Operating Position to Set Position 1 (P1), where the crown is half extended at the first adjustment click.
2. In Set Position 1 (P1) the watch will continue ticking during adjustment. Turn the crown clockwise until the correct date is displayed.
3. When the date is set, push the crown back to the Operating Position.

Please note: The date should be set before 12 noon so that the calendar indicator changes in sync at twelve midnight and not twelve noon.

Please note: Whilst the crown is in either Set Position 1 or 2 the watch is not moisture resistant.

Watch care

Your Uniform Wares watch requires a certain amount of care. The following guidelines will enable you to ensure its reliability and protect its appearance over time.

Cleaning

Please use a clean, lint-free cloth with warm water or, if required, a mild detergent diluted in water to remove any dirt from the case. To clean the lens use a clean chamois cloth. Avoid submerging the watch case in water.

Battery

Your watch's power source is a Swiss-made Renata cell which has an estimated lifespan of 60 months. When your battery requires replacing, please refer to the Uniform Wares website www.uniformwares.com/service for information on battery replacement.

Water resistance

This watch is designed to withstand everyday use and has a 5ATM water resistance rating. Exposure to high humidity and light rain showers is acceptable. However, you should avoid wearing the watch whilst showering, swimming, diving or during any other activity where it may be subjected to abnormal water pressures or environments where abnormal heat and moisture are present (e.g. saunas or hot tubs). This combination may have a negative effect on the seals and gaskets of the watch.

Condensation

If your watch experiences a sudden change in temperature or pressure, a slight condensation may appear under the sapphire glass. This mist should disappear by itself and will not affect the functioning of your watch. If the condensation persists, please contact www.uniformwares.com/service.

Warranty

Two Year International Warranty

Your Uniform Wares watch is warranted by Uniform Wares for a period of two years from the original date of purchase under the terms and conditions of this warranty. The Uniform Wares warranty covers materials and manufacturing defects. The warranty comes into effect if you have a copy of the receipt, this is required for proof of purchase.

During the warranty period, the watch movement, hands, and dial are the only components covered under this warranty. If the covered component proves to be defective in material or craftsmanship under normal use, it will be repaired or the watch will be replaced free of repair charges. In case of replacement, Uniform Wares cannot guarantee that you will receive the same model watch. If your model is not available, a watch of equal value and similar style will be provided.

The warranty for the replacement watch ends two years from the date the replacement watch is received.

This Warranty Does Not Cover:

- Any defects in materials and workmanship of battery, case, crystal, strap, or bracelet.
- Damage resulting from improper handling, lack of care, accidents, or normal wear and tear.
- Defect of internal or external components due to contact with water or moisture.

This warranty is void if the watch has been damaged by accident, negligence of persons other than authorised Uniform Wares sales or services agents, unauthorised service, or other factors not due to defects in materials or workmanship.

The foregoing warranties and remedies are exclusive and in lieu of all other warranties, terms or conditions, express, implied or statutory, as to any matter whatsoever, including, without limitation, warranties of merchantability, fitness for a particular

purpose, accuracy, satisfactory quality, title, and non-infringement, all of which are expressly disclaimed by Uniform Wares. Uniform Wares shall not be liable for incidental, consequential, indirect, special or punitive damages, or liabilities of any kind arising out of or in connection with the sale or use of this product, whether based in contract, tort (including negligence), strict product liability or any other theory, even if Uniform Wares has been advised of the possibility of such damages and even if any limited remedy specified herein is deemed to have failed of its essential purpose. Uniform Wares' entire liability shall be limited to replacement or repair of the purchase price paid, at Uniform Wares' sole option.

Some countries, states, or provinces do not allow the exclusion or limitation of implied warranties or the limitation of incidental or consequential damages so the above limitations and exclusions may be limited in their application to you. When implied warranties may not be excluded in their entirety, they will be limited to the duration of the applicable written warranty. This warranty gives you specific legal rights; you may have other rights that may vary depending on local law. Your statutory rights are not affected.