


ADAPT


What's in the box

Quick Start Guide


Guide de démarrage rapide



Buttons



Connections



App



Download the Harman Kardon Controller app to setup and control your Harman Kardon Adapt.

Téléchargez l'application Harman Kardon Controller pour configurer et commander votre Harman Kardon Adapt.

Descargue la aplicación Harman Kardon Controller para configurar y controlar su Harman Kardon Adapt.

Baixa o app de controle da Harman Kardon para configurar e controlar o Harman Kardon Adapt.

Laden Sie die Harman Kardon Controller-App herunter, um Ihren Harman Kardon Adapt konfigurieren und bedienen zu können.

Scarica l'app Harman Kardon Controller per impostare e controllare il tuo Harman Kardon Adapt.

Download de Harman Kardon Controller app om uw Harman Kardon Adapt te installeren en te bedienen.

Last ned Harman Kardon Kontroll-appen for å sette opp og kontrollere Harman Kardon Adapt.

Lataa Harman Kardon Controller-sovellus, jotta voit määrittää Harman Kardon Adapt -laitteen asetukset ja hallita sitä.

Загрузите приложение Harman Kardon Controller, чтобы настроить свой продукт Harman Kardon Adapt и управлять им.

Hämta appen Harman Kardon Controller för att ställa in och styra din Harman Kardon Adapt.

Hent applikationen Harman Kardon Controller, så du kan konfigurere og styre din Harman Kardon Adapt.


Harman Kardon Controller (ハーマンカードン・コントローラー)アプリをダウンロードしてセットアップし、お持ちの Harman Kardon Adapt (ハーマンカードン・アダプト) をコントロールしてください。

Harman Kardon Controller 앱을 다운로드하여 Harman Kardon Adapt 을 설정하고 제어합니다.

下載 Harman Kardon Controller 應用以設置和控制您的 Harman Kardon Adapt。


Unduh aplikasi Harman Kardon Controller untuk persiapan dan mengontrol Harman Kardon Adapt Anda.

WPS (Wi-Fi Protected Setup)




Status	LED
Connecting	
Connected	

Wi-Fi streaming via Harman Kardon Controller app




Status	LED
Wi-Fi connected	
Wi-Fi streaming	

Bluetooth*




Status	LED
Pairing mode	
Connected	
Streaming	

AUX input source



Status	LED
Aux active	
System idle	
Auto standby (15 minutes)	

Multi-room music streaming



Status	LED
Wi-Fi streaming	

Party Mode



Current Source	LED	
Bluetooth*		
AUX		
Wi-Fi Streaming		

